

UPGRADE TO MERSEN

AMP-TRAP 2000® FAMILY FOR TOTAL SYSTEM PROTECTION



CLASS CC FUSES 3 AMPS AND ABOVE*

EXISTING FUSE:

511	FNM
512	FNQ
5AG	FNQ-R
6JX	GGU
AGU	FNW
A6Y-2	HCLR
A6Y-2B	KLDR
ATM	KLK
ATMR	KLK-R
ATQ	KLK-D
BAF	KLM
BAN	KTK
BLF	KTK-R
BLN	LP-CC
CCMR	MCL
CM	MEN
CMF	MEQ
CNM	MOF
CNQ	MOL
CMC	OTM
CTK-R	TRM
FLM	SKM2
FLQ	SKM6

* Below 3 amps, use ATQR Series for all class CC and Midget fuses.

UPGRADE TO:

ATDR (amp)

CLASS J 600V

EXISTING FUSE:

A4J	JCL
CJ	JHC
C-J	JKS
CJS	JLS
GF8B	JTD
J	LPJ
JA	SJ

UPGRADE TO:

AJT (amp)

CLASS RK1 250V

EXISTING FUSE:

10K0TN	KON
50K0TN	KTNR
A2KR	KWN-R
AT-DE	KWN-R
CH-G	LENRK
CRN	LLNRK
CSN-R	LON-RK
CTN-R	LPNRK
DEN-R	NCL-R (600A and BELOW)
DLNR	
ECN(-R)	NLN
EON	NON
ERN	NRN
FLNR	OT
FRN	REN
FRN-R	RF
HB	RFN
HNR	RLN
KLNR	TR-R
KN	TR-RID

UPGRADE TO:

A2D (amp) R

CLASS RK1 600V

EXISTING FUSE:

10K0TS	KTSR
A6K-R	KWS-R
ATS-DE	LESRK
CH-R	LLSRK
CRS	LOS-RK
CSS-R	LPSRK
CTS-R	NLS
DES-R	NOS
DLSR	NRS
ECSR	OTS
EOS	RES
ERS	RFS
FLSR	RHS
FRS	RLS
FRS-R	SCL-R
HSR	SCLR-S
IDSR	TRS-R
KLSR	TRS-RID
KOS	

UPGRADE TO:

A6D (amp) R

CLASS L 600V

EXISTING FUSE:

A4BY	KRPC-L
CL	KRPC-W
CLL	KTU
CLU	L
KLLU	LCL
KLP-C	LCU
KLU	WCL
KRP-C	

UPGRADE TO:

A4BQ (amp)